



PLAN VIEW

NOTES:

1. COVER MANHOLE WITH BUILDING PAPER AND CONSTRUCT ASPHALT CONCRETE BASE COURSE AND WEARING COURSES.
2. SAWCUT SQUARE EXCAVATION AROUND MANHOLE 12" MIN FROM MANHOLE FRAME.
3. RAISE MANHOLE COVER AND FRAME TO FINISH GRADE BY INSTALLING CONCRETE MANHOLE ADJUSTMENT RINGS AND LEVELING MORTAR, AS SHOWN.
4. BACKFILL WITH EARLY STRENGTH PORTLAND CEMENT CONCRETE. ALL CONCRETE SHALL BE COMMERCIAL GRADE CONCRETE.
5. PROTECT FROM TRAFFIC LOADING UNTIL CONCRETE HAS CURED TO 3000 PSI.
6. APPLY TACK COAT TO EDGES OF EXISTING PAVEMENT BEFORE INSTALLING PATCH.
7. FINISH JOINT WITH ASPHALT SEAL AND SAND.
8. SEE STD DWG RD.356-W FOR MANHOLE COVERS AND FRAMES.
9. SYNTHETIC GRADE RINGS SHALL BE SECURED WITH EPOXY PER CITY STANDARDS.

NOTES:

1. THIS DETAIL HAS BEEN MODIFIED BY THE CITY OF WINSTON. ALL MATERIAL AND WORKMANSHIP SHALL BE IN ACCORDANCE WITH THE CURRENT OREGON STANDARD SPECIFICATIONS.



WINSTON STANDARD DRAWING

MANHOLE FRAME ADJUSTMENT